




Общий вид сбоку



Колочки ABE-7H/P/R/S




Крепление комплектом ABE-7ACC01




1 дополнительная шунтирующая клеммная колодка ABE-7BV20

	a	b	c	d	e
ABE-7					
H08R1●/H08R21	84	70	82	58	67
H08S111	84	70	82	58	67
H12R1●/H12R2●	125	70	82	58	67
H12R50	84	70	82	58	67
H16●43	206	70	82	58	67
H16R1●/H16R2●/H16R3●	125	70	82	58	67
H16R50	84	70	82	58	67
P16F31●	272	89	101	74	83
P16T3●●	272	89	101	74	83
P16T2●●	211	89	101	64	73
R08S111	84	77	89	58	67
R08S210/R08S2B0	125	77	89	58	67
R16S11●	125	70	82	58	67
R16S21●	206	70	82	58	67
R16T2●●	211	89	101	64	73
R16T3●●	272	89	101	74	83
S08S2B1	206	77	89	58	67
S16E2●●	206	77	89	58	67
S16S1B2	125	77	89	58	67
S16S2B0	206	77	89	58	67
CPA01	143	70	82	58	67
CPA02/CPA03	125	70	82	58	67
CPA11/CPA12	143	70	82	58	67
CPA21	84	70	82	58	67
CPA31	206	77	89	58	67


Разделительная колодка ABE-7ACC02




Колодка ввода/вывода с резервированием ABE-7ACC10/11




Кабельный ввод ABE-7ACC80



Кабельная муфта ABE-7ACC84



Кабельный ввод ABE-7ACC82, ABE-7ACC83



Колодка-эмулятор ABE-7TES160

